

# MODEL 2852-LPS WITH S00445C LEAK SENSOR

## Area Leak Alarm

### User Manual

Technical Support  
Continental North America Toll Free 1-(800) 387-9487  
Ph: +1 (905) 829-2418 Fx: +1 (905) 829-4701



A Product of Arjay Engineering Ltd.  
Oakville, Ontario, Canada

[www.ArjayEng.com](http://www.ArjayEng.com)

MODEL:	
HARDWARE NO.:	5.1
SOFTWARE NO.:	
SERIAL NO.:	

## TABLE OF CONTENTS

1.0	INSTRUMENT OVERVIEW .....	3
1.1	Features .....	3
1.2	Model Number vs. Voltage Input.....	3
1.3	Specifications .....	4
2.0	INSTALLATION.....	6
2.1	Controller Installation .....	6
2.1.1	Permanent Power Connection (AC Powered Models only) .....	6
2.2	Sensor Installation (Probe Style) .....	7
2.3	Electrical Installation .....	8
2.3.1	Input / Output Terminal Specification .....	9
2.4	Glossary of Symbols .....	10
3.0	STARTUP AND CALIBRATION.....	11
3.1	Startup.....	11
3.2	Menu Flow Chart Background Information .....	11
3.2.1	Menu Description.....	11
3.2.2	Menu Flow Chart .....	11
3.2.3	Data Entry.....	12
3.3	2852 Controller Calibration .....	12
3.3.1	Site Calibration .....	12
4.0	SETUP, ALARMS and DIAGNOSTICS .....	13
4.1	2852 Controller Setup .....	13
4.2	2852 Controller Alarms .....	13
4.3	2852 Controller Diagnostics.....	14
4.4	2852 Controller Network .....	14
4.4.1	Modbus Configuration .....	14
4.4.2	2800 Series Modbus Register Mapping .....	15
5.0	MAINTENANCE .....	16
6.0	TROUBLESHOOTING .....	17
7.0	FLOW CHARTS .....	18

## TABLE OF FIGURES

Figure 1 – Electrical Installation Overview .....	8
---	---

## 1.0 INSTRUMENT OVERVIEW

The Arjay Area Leak Alarm provides a means for detecting liquid spills and leaks in containment bunkers, equipment pans, equipment rooms, sub-floors, or anywhere the presence of a liquid should be alarmed. The leak probe design allows the sensor to monitor for low dielectric materials such as diesel, oils etc while maintaining a stable reading during possible shifts in temperature. The sensing assembly contains a capacitance probe that monitors the air to floor space below and around the probe. Air has a low dielectric constant, which results in a low capacitance reading. When a liquid submerges the sensing probe, the capacitive field increases and triggers the alarm. The system can be sensitized to very low dielectric liquids such as diesel.

The complete 2852-LPS system has two options:

Option 1: Part# S00455A comes with one controller, one PMC 2800TMP and one leak sensor (S00455C).

Option 2: Part# S00455B comes with two controller, two PMC 2800TMP and two leak sensor (S00455C).

The capacitance leak sensors are constructed of chemical resistant Teflon, 304/316 stainless steel. A PMC 2800TMP card is mounted in the sensor junction box which translates the capacitance signal from the sensor into a frequency pulse, which can then be transmitted back to the 2852 controller via 3-wire shielded cable (50ft of cable supplied with each sensor). There is a built-in temperature sensor in the PMC 2800TMP which helps compensate for any change in capacitance due to temperature changes.

The model is intended for use in General Purpose non-hazardous areas. For hazardous location use refer to Arjay Engineering Ltd. for appropriate model.

### 1.1 Features

- Microprocessor based capacitance Controller
- Relay and 4/20mA alarm output
- Modbus protocol via RS-485 for access by Arjay handheld, Central Access Panel or compatible system
- Local Auto calibration or remote calibration via network
- User specified custom features may be added by contacting Arjay Engineering Ltd.

### 1.2 Model Number vs. Voltage Input

- 2852-LPS-1-X 100-240 VAC power input
- 2852-LPS-3-X 12 VDC power input
- 2852-LPS-4-X 24 VDC power input

Where "X" = Temperature Comp. circuit.

### 1.3 Specifications

<b>Power Input:</b>	12 VDC +15% /-10% or 24 VDC +15% /-10%, 250mA maximum 100VAC – 240VAC +/- 10%, 50/60 Hz, 150mA maximum <b>Note:</b> DC input models must be supplied by Limited Energy power source. Limited Energy means compliance with one of the following requirements: <ul style="list-style-type: none"> <li>- Class 2 circuit according to Canadian Electrical Code, Part, I, C22.1;</li> <li>- Class 2 circuit according to National Electrical Code, NFPA-70;</li> <li>- Limited Power Supply (LPS) according to IEC 60950-1;</li> <li>- Limited-energy circuit according to IEC 61010-1.</li> </ul>
Connections to mains supply	Permanent (for AC/DC model)
<b>User Interface:</b>	
Display & Keypad	Two line LCD with display of Alarm Status, select menu or enter values by keypad (display is internal to housing and used for set-up and diagnostics only)
Communication Interface:	Modbus (RS485)
<b>Analog /Relay Outputs:</b>	
mA Signal Output	4 mA during Normal and 20 mA during an alarm condition, 900 Ohms max OR 450 Ohms max (12VDC Power)
Relay Output	2 SPDT relay, dry, N.O. Contact 5 A @ 250 VAC (Resistive) and N.C. Contact 3 A @ 250VAC (Resistive), selectable failsafe or non-failsafe, selectable high or low acting alarm, programmable time delay: 0 – 600 seconds
<b>Instrument Performance:</b>	
Setpoint Range of S00455C Sensing Probe	6mm – 14mm of surface liquid (Dependent on dielectric of material)
Measuring Range	0 - 5000 pF (most applications are 100pF to 1000pF)
Accuracy	0.2% of setpoint
Resolution	0.05% of setpoint via network display 0.002% of Full Scale capacitance via network display
Calibration	Single point: Auto calibration
<b>Environmental:</b>	
Operating conditions	Continuous
Operating Temperature	-20 °C to +55 °C 2852-LPS controller -40 °C to +55 °C PMC 2800TMP -60 °C to +200 °C Sensor Probe (S00445C)
Relative humidity	0 to 95% (non-condensing)
Altitude	≤2000 m

Installation Category	II
Pollution Degree	2
Equipment mobility	Fixed
<b>Mechanical Specification:</b>	Refer to Dimensional Drawing
Enclosure Rating	Type 4 / IP65 Painted Steel Type 4x / IP66 Polycarbonate Type 4x / IP66 316 Stainless Steel
Options on Enclosure	Buzzer Pilot Light OR Strobe/Beacon Custom alarms
<b>Approval Standards:</b>	<ul style="list-style-type: none"> <li>• UL / IEC 61010-1, 2<sup>nd</sup> Edition, 2005-07-22 (Electrical Equipment for Measurement, Control, and Laboratory Use; Part 1: General Requirements)</li> <li>• UL file number: E343390</li> <li>• CAN/CSA-22.2 No. 61010-1, 2<sup>nd</sup> Edition, 2004-07, (Electrical Equipment for Measurement, Control, and Laboratory Use; Part 1: General Requirements)</li> <li>• CE: UL / IEC 61010-1; IEC / EN 61000-4; ISO 9001:2008</li> </ul>

## 2.0 INSTALLATION

**NOTE: If any damage to the instrument is found, please notify an Arjay Engineering representative as soon as possible prior to installation.**

### 2.1 Controller Installation

Choose the mounting location in accordance with good instrument practice. Main controller should be mounted above any possible flood area. Extremes of ambient temperature and vibration should be avoided (see specifications and installation drawing).

The 2850 controller may be mounted up to one kilometer from the PMC 2800TMP card (mounted in sensor junction box) using a minimum 20 gauge, 3-wire SHIELDED cable (Belden 8772 or Equivalent). 50ft of cable is supplied with each sensor.

Check the polarity of the + and - wiring between the controller and the PMC prior to powering on the unit; + to + and - to - to avoid damage. Ensure that the temperature wire (Marked "T") is connected at the controller temperature connector (TB7). Shield of cable should be connected to secondary ground terminal marked as  $\perp$  at controller only (Dead end shield at PMC junction box). Incoming Earth ground should be connected to primary ground terminal marked  $\oplus$  on sub plate.

**Important Note: The controller is factory set in a Failsafe mode.** This means that the relays are in an energized state during normal operation. The N.O. relay contact will be held closed and the N.C. relay contact will be held open during a normal condition. This will allow the relay to return to its non-energized (shelf) state during an alarm, fault or power failure condition. Wire accordingly.

Note: Maximum Conduit size for installation size is  $\frac{3}{4}$ " FNPT.

#### 2.1.1 Permanent Power Connection (AC Powered Models only)

- 1) Connection to the building wiring system shall be in accordance with the Canadian Electrical Code (CEC), Part 1 in Canada, the National Electrical Code, ANSI/NFPA 70 in the USA, or the local electrical codes of the country where the equipment is being installed.
- 2) A disconnecting device is required. The disconnecting means shall disconnect all current-carrying conductors.
- 3) 15A circuit breaker or equivalent fuse is required.
- 4) An external switch or breaker shall be in close proximity to the equipment and within easy reach of the operator. The switch shall be marked as the disconnecting device for the equipment and include the symbols to its "ON" and "OFF" positions using the following symbols:



Power Off



Power On

- 5) The wiring for AC power should be minimum 18 AWG / 300V or as required by local / country codes.
- 6) After field wiring, the primary wires must be secured to the enclosure by tie-wraps to maintain the separation from the signal wires.
- 7) Wiring diagram for permanent connection: See drawings at the back of this manual.
- 8) Use copper conductors only.

## 2.2 Sensor Installation (Probe Style)

Sensors should be mounted in a containment area OR at the lowest elevation in the area so that the liquid can pool around the sensor.

Once installed, wire each sensor back to the main controller using the 50ft of 3 wire cable supplied. See electrical detail drawing in back of this manual.

### **NOTES:**

**The sensors are not for mounting outdoors or in locations where rain or liquid splashing may cause nuisance alarms.**

**To ensure proper operation and electrical safety, make sure the 2852 enclosure and the PMC junction box are electrically grounded.**

**If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.**

## 2.3 Electrical Installation




Figure 1 – Electrical Installation Overview

### TB1/TB2 - Relay Output

2 SPDT relay, Dry, N.O. Contact 5A @ 250 VAC (Resistive) and N.C. Contact 3A @ 250VAC (Resistive), selectable failsafe or non-failsafe, selectable high or low acting alarm, programmable time delay: 0 – 600 seconds

### TB3 - Power Input

Power input as per Model. Check if ordered AC or DC. . Earth ground is connected to G.

### TB4 - Network Output

Connect RS485 + and – to the network D+ and D-.

### TB5 - 4/20 mA Output (+ and -)

The 4/20 mA is a sourced output referenced to Ground. It is not loop powered.  
4mA = Normal                      20mA = Alarm

### TB6 - Probe Input

Connect '+' to '+', '-' to '-' between the controller and the PMC card. Check polarity to avoid damage.

### TB7 – Temperature Compensation



### 2.3.1 Input / Output Terminal Specification

<b>Input Terminals – Power Source</b>					
<b>Terminal ID</b>	<b>Overtoltage category</b>	<b>Rated Voltage (V)</b>	<b>Rated Current/power (A/W/VA)</b>	<b>— HZ or DC</b>	<b>Specified Mains fluctuation</b>
<i>TB3</i>	<i>II</i>	<i>100-240V</i>	<i>150mA</i>	<i>50/60Hz</i>	<i>± 10%</i>
<i>TB3</i>	<i>II</i>	<i>12 OR 24V</i>	<i>250mA</i>	<i>DC</i>	<i>+15%</i> <i>-10%</i>









<b>Input Terminals – Measuring Circuits</b>					
<b>Terminal ID</b>	<b>Function</b>	<b>Measurement Category</b>	<b>Nominal a.c. or d.c line to neutral voltage / if CAT I, Max. transient overvoltage Ut</b>	<b>Nominal a.c. or d.c current</b>	<b>Rating of insulation required for external circuit</b>
<i>TB6</i>	<i>Frequency</i>	<i>I</i>	<i>15V, 50mA / 0</i>	<i>--</i>	<i>DI * or RI**</i>
<i>TB4</i>	<i>RS485 Communication</i>	<i>I</i>	<i>5V, 5mA / 0</i>	<i>--</i>	<i>DI * or RI**</i>

\* Double Insulation

\*\*Reinforced Insulation

<b>Output Terminals</b>					
<b>Terminal ID</b>	<b>Function</b>	<b>Isolation or protection</b>	<b>Rated V, A</b>	<b>Max. V, A</b>	<b>Load type and nominal</b>
<i>TB1</i>	<i>Load</i>	<i>Relay</i>	<i>N.O. Contact 5A @250VAC &amp; N.C. Contact 3A @250VAC</i>	<i>--</i>	<i>--</i>
<i>TB2</i>	<i>Load</i>	<i>Relay</i>	<i>N.O. Contact 5A @250VAC &amp; N.C. Contact 3A @250VAC</i>	<i>--</i>	<i>--</i>
<i>TB5</i>	<i>Current</i>	<i>Isolator(optional)</i>	<i>- 18V, 20mA, 900Ω - 9V, 20mA, 450Ω</i>	<i>50mA @18V</i>	<i>--</i>
<i>TB7</i>	<i>Voltage</i>	<i>None</i>	<i>5VDC, 30mA</i>	<i>--</i>	<i>Temperature</i>

## 2.4 Glossary of Symbols

	Attention, consult accompanying documents Attention, veuillez consulter les documents ci-joints.		
	Protective Earth Terre de protection		Fuse Coupe-circuit; fusible
	Direct Current (DC) Courant continu		Normally open relay contacts Contacts travail
	Normally closed relay contacts Contacts Repos		Power off Arrô (mise hors tension)
	Power on Marche (mise sous tension)	<b>L</b>	Live Sous tension
<b>N</b>	Neutral Neutre	<b>G</b>	Ground Terre

## 3.0 STARTUP AND CALIBRATION

### 3.1 Startup

Check that the power wiring and PMC wiring are wired in accordance with the electrical installation drawing.

Power On the unit. Allow a 1 hour warm-up period before calibrating.

The Status LED on the controller circuit board should be green. A red Status LED indicates a fault condition. If red, check the Troubleshooting section.

**The unit is pre-configured and tested at the factory. However, a quick field calibration is required after power up to tune the sensor to the installation and cable conditions. See section 3.3 to calibrate the 2852-LPS.**

### 3.2 Menu Flow Chart Background Information

The control setup, diagnostics, and calibration are accessed using the display and keypad on the controller. The Flow Chart in Section 7.0 provides an overview to the various menus and features. Keep a copy of the flow chart at hand when accessing the internal controller features.

Below is a description of the menu functions.

#### 3.2.1 Menu Description

Since the 2852 controller has a small LCD, some menu descriptions may be in short form. The following are the menu descriptions:

<i>Diags:</i>	<i>Diagnostics</i>	<i>SENSTVTY:</i>	<i>Sensitivity</i>
<i>Cal Pts:</i>	<i>Calibration points</i>	<i>A1:</i>	<i>Alarm relay 1</i>
<i>Auto Cal:</i>	<i>Auto calibrate</i>	<i>A2:</i>	<i>Alarm relay 2</i>
<i>Man Cal:</i>	<i>Manual calibrate</i>	<i>Alrm:</i>	<i>Alarm</i>
<i>Cal Ok:</i>	<i>Calibrate ok</i>	<i>Alrm Lvl:</i>	<i>Alarm level</i>
<i>Cal Err:</i>	<i>Calibrate err</i>	<i>Diff Hi:</i>	<i>Differential Hi alarm set value</i>
<i>mA out:</i>	<i>mA output</i>	<i>Diff</i>	<i>Differential Lo alarm set value</i>
<i>mA Span:</i>	<i>mA output span</i>	<i>Alrm Del:</i>	<i>Alarm Delay</i>
<i>Sec:</i>	<i>Seconds</i>	<i>^SP:</i>	<i>Relay Setpoint High action</i>
<i>ALRM CAL:</i>	<i>Alarm Calibration</i>	<i>vSP:</i>	<i>Relay Setpoint Low action</i>
<i>Cal:</i>	<i>Calibration point</i>	<i>TEMP:</i>	<i>Temperature</i>
<i>Tcomp pF:</i>	<i>Compensated capacitance</i>	<i>Change:</i>	<i>Temperature change compare to Temperature at</i>

#### 3.2.2 Menu Flow Chart

The 2852 controller will display **Normal** in its normal operating condition and **Alarm** during a liquid leak condition.

From the main menu, you can select **Cal Only**, **View**, and **Change**.

**Cal Only** allows a user to calibrate after the equipment is installed. The calibration is required at site after power up or anytime a component or sensor is changed out. A password is required to enter this and is described in the calibration section.

**View** allows an operator to view the **Calibration** setpoints in pF, the **Alarms** settings (2852 only) such as low or high action, failsafe or non-failsafe and the 0-600 second delay, the

**Diagnostics** of raw readings and the **Setup** values such as mA output and ID address. This can be viewed without a password and without risk of changing any values. This information may be requested during technical assistance inquiries.

**Change** is password protected and allows an operator to enter or change the configuration set-up values indicated in the View. Changes will be required for the initial setup of relay setpoints, delays, span etc. or to re-set the values to the factory default.

### 3.2.3 Data Entry

Data Entry


Press <▲> / <▼> key to increase / decrease the digital value.

Press <SELECT> key to move the cursor.

Press <MENU> key to abort certain screens

### 3.3 2852 Controller Calibration

Power up the 2852 Controller. The status LED should be green. The LCD will scroll to the normal operating screen after a series of the following screens (each display for 2 sec.). It may read **Normal** or **Alarm** until a calibration is performed.



#### 3.3.1 Site Calibration

A factory pre-configuration and set-up has been defaulted into the 2852-LPS. As such, a user set-up is not required in the field. A basic calibration is only required.

Be sure all the sensors are wired and placed in their proper location before calibrating.

Allow one hour warmup before proceeding to calibration.

As per the Flow Chart, press and hold Menu key for 5 seconds to enter the main menu. The display will read the first menu item **Cal only**. Press select key, enter password "2000". A pF reading of the sensor will be displayed. Press select to acknowledge and then press select to accept the new calibration. To abort, press the MENU key.

If the calibration is successful, the display will return to the main operating display.

To verify the LPS sensor and electronics are responsive, place a hand on the sensing probe. The controller LCD should start to count down from its preset time-delay. The high dielectric of your hand simulates a leak condition. Verify that the control unit alarms.

The Alarm1 and Alarm2 LEDs on the circuit will activate red. Remove your hand and the alarm will clear.

For more accurate test, you may be required to test with the type of liquid that may potentially spill.

If the calibration is successful, the display will return to the main operating display and show normal condition.

**THIS COMPLETES THE SETUP AND CALIBRATION PROCEDURE FOR THE  
2852-LPS Area Leak Alarm**

## 4.0 SETUP, ALARMS AND DIAGNOSTICS

### 4.1 2852 Controller Setup

The 2852 controller has the following Setup parameters:

#### 1. Sensitivity

The sensitivity determines the amount of pF change required to cause an alarm. The factory default setting is 4.0 pF. Increasing the pF value will increase the amount of liquid required to cause an alarm. Since different liquids have different dielectrics, a pF to mm of liquid level relationship cannot be factory determined.

As a general guideline for LPS sensor (Rev2.0), the maximum recommended sensitivity adjustment for Water (High Dielectric Constant of 80) is 20pF and for Oil (Low Dielectric Constant of 2.2) is 5pF. This is based on detecting a maximum depth of 14mm.

If this setting is changed in the field, it should be tested to confirm an alarm.

#### 2. Alarm Calibration above or below setpoint

This setting advises the controller if the calibrated pF value is above or below the alarm setpoint. For the LPS, the calibration pF value is below the setpoint because the unit is required to alarm at a higher pF value, which indicates a leak. The factory default is Above Setpoint.

#### 3. Defaults

Factory settings are pre-configured into the unit based on the most typical set-up required for this application. This provides for a quick and easy calibration at site but can be changed for special applications. If the setup has been changed, this will change back to the factory defaults.

#### 4. Net ID

The ID number is used only for network applications. To communicate on a network, each controller must have a unique ID number. The factory default ID number is 1.

Important: If multiple units on a network have the same address, network errors will result.

#### 5. Filter

Data filtering is used to smooth data from a sudden change and minimize fluctuating readings. For example, a 5 second setting means the calculated value of the capacitance and resulting values of pF will start to respond immediately but will take 5 seconds to reach their final values. The factory default is 0 to provide an immediate and active response.

### 4.2 2852 Controller Alarms

The two relays on the 2852 operate together. The follow parameters are available as a common setting to the two relays:

#### 1. Delay

Minimum time in seconds for an alarm to exist before the relays change to an alarm state. The relay alarm state depends on the Relay Action and Failsafe settings. The factory setting is 15 seconds. to suppress false alarms due to sudden or intermittent disturbances in front of the sensor.

#### 2. Action

This determines if the Alarms LEDs should activate when the pF reading rises above or below the setpoint. The factory default is Above the setpoint because the application of air to liquid is an increase in capacitance.

### 3. Failsafe

Failsafe typically means that the relay is held in an energized state when in a normal operating condition as opposed to an alarm condition. In an alarm condition, the relay de-energizes which is identical to when the instrument power is shut off. The rationale is that the alarm condition should match the Power Fail condition. The factory default is Yes for Failsafe.

## 4.3 2852 Controller Diagnostics

The 2852 controller has the following Diagnostic parameters:

### 1. Frequency and Capacitance (pF & Hz)

These are the frequency and capacitance of the leak sensor.

**NOTE:** The following are temperature sensor options and are available *ONLY* when ordered by customer

### 2. Temperature (TEMP)

The temperature reading from the temperature sensor embedded within the PMC 2800-TMP card.

### 3. Temperature Change (CHANGE)

The 2852 controller captures temperature during the calibration and records it as temperature@Cal. The temperature change is the difference between the temperature@Cal and the current temperature (parameter 2 above). This temperature change parameter will be used in temperature compensation.

### 4. Compensated Capacitance (Tcomp pF)

The compensated capacitance is calculated from the current capacitance (parameter 1) and temperature change (parameter 3) by a compensation formula which is factory set. Factory setting is 0.018%.

## 4.4 2852 Controller Network

The 2852 Controller may be monitored and calibrated via RS-485 protocol compatible digital communications.

Typical features are:

### 1. Ease of wiring in multiple level point monitoring:

Up to 255 Model 2852's (or other Arjay 2800 Series level monitors) may be connected together in a daisy chain (2 wire communication plus power wiring) connection to an Arjay Remote Access monitor or customer control system which allows viewing data and setup of any of the transmitters on the network. The relay and analog outputs may still be used if necessary.

### 2. Setup for the 2852 for network operation:

Each 2852 transmitter must have a unique ID number to connect in a network system.

#### 4.4.1 Modbus Configuration

Parameter settings: 9600 Baud Rate; Even Parity, 8 Data Bits and 1 Stop Bit.

Wiring connection: RS485 (+) connect to D+; RS485 (-) connect to D-

#### 4.4.2 2800 Series Modbus Register Mapping

REG	Zero Based	DESCRIPTION	TYPE	No. of Reg
40001	0	Serial Number	float	2
40003	2	Hardware Rev / Software Rev	byte	1
40004	3	Sensitivity / Mode	byte	1
40005	4	Instrument Status	int	1
40006	5	Model / Modbus Address	byte	1
40007	6	Relay2 Setup / Relay 1 Setup	byte	1
40008	7	Password	int	1
40009	8	XA "A" cal parameter	float	2
40011	10	XK "K" cal parameter	float	2
40013	12	XC "C" cal parameter	float	2
40015	14	Filter	float	2
40017	16	Slope – pF per % level	float	2
40019	18	Offset – pF for empty vessel	float	2
40021	20	mA output span value	float	2
40023	22	mA output Zero value	float	2
40025	24	mA output Trim Slope value	float	2
40027	26	mA output Trim Offset vlaue	float	2
40029	28	Cal1 PV: 1st calibration point level value in %	float	2
40031	30	Cal2 PV: 2nd calibration point level value in %	float	2
40033	32	Cal1 pF: 1st calibration point capacitance value in pF	float	2
40035	34	Cal2 pF: 2nd calibration point capacitance value in pF	float	2
40037	36	Relay 1 : Differential High Alarm [% Level]. Only used for Linear Level type. Not used for Single Point Alarm application	float	2
40039	38	Relay 2: Differential High Alarm [% Level]. Only used for Linear Level type. Not used for Single Point Alarm application	float	2
40041	40	Relay 1: Differential Low Alarm [% Level] OR Single Point Alarm [pF]. Single Point Cal: used as captured pF during cal	float	2
40043	42	Relay 2: Differential Low Alarm [%Level]. Only used for Linear Level type. Not used for Single Point Alarm application	float	2
40045	44	Relay 1 On delay [in seconds]. Only used for Linear Level or Single Point Alarm application	int	1
40046	45	Relay 2 On delay [ in seconds]. Only used for Linear Level type. Not used for Single Point Alarm application	int	1
40047	46	mA Analog Output	float	2
40049	48	Oscillation Frequency	float	2
40051	50	Frequency	float	2
40053	52	Capacitance	float	2
40055	54	Filtered Capacitance	float	2
40057	56	Level	float	2
40059	58	Compensated pF for point level [Uncompensated for other models]		2
40061	60	Temperature mV		2

40063	62	Temperature dC		2
40065	64	Compensated factor: percent per degree		2
40067	66	Temperature at Calibration		2
40069	68	Temperature offset [mV at 0dC]		2
40071	70	Temperature slope [mV per dC]		2

## 5.0 MAINTENANCE

There is no routine cleaning required for this controller.



## 6.0 TROUBLESHOOTING

CONDITION	DO THIS
1. Status LED is OFF and the LCD display is off	Check the power to the unit. If the unit is a 12VDC or 24VDC model, check the external source and polarity is correct. If the unit is a 100-240VAC model, then check the Line, Neutral and Ground wiring is correct.
2. If the status LED is RED	This indicates a major error such as memory failure, no probe signal etc. Check the following: <ul style="list-style-type: none"> <li>• Make sure the PMC is installed</li> <li>• Make sure the PMC wiring is correct and there are no breaks in the wiring. At the controller, measure across the Probe Input terminals with a DC meter. Make sure "Common" lead of meter is on '-' terminal. It should read (+) 8 to (+)10 VDC with the PMC connected and approximately 20 to 24 VDC with the PMC terminal disconnected.</li> <li>• Microprocessor may have lost its parameters due to a surge in the line. Go to Diagnostic Menu (see Flow Chart) to check the Calibration values, frequency and capacitance values</li> <li>• Call Arjay Technical Support.</li> </ul>
3. No mA output OR incorrect mA output.	<b>IMPORTANT: THE UNIT <u>SOURCES</u> mA OUT FROM THE mA OUTPUT TERMINAL. <u>THIS TERMINAL SHOULD NOT BE CONNECTED TO +24V</u>. IT IS NOT A 2 WIRE mA TRANSMITTER. See Figure 4 for Electrical hookup details.</b> <ul style="list-style-type: none"> <li>• Disconnect external wires from mA output and measure with mA Meter.</li> <li>• Check the mA output Action (direct or inverse) and mA output Span are set as desired. See section 7.0 Flow chart / Change menu.</li> <li>• If the mA output still does not match the level, then call Arjay Technical Support.</li> </ul>
4. False Alarms	<ul style="list-style-type: none"> <li>• Add some time delay in the unit</li> <li>• Make sure there is no external interference and electrical noise such as motors, high voltage interference, splashing, etc</li> <li>• Adjust the sensitivity to the next higher value. Test after any changes to confirm an alarm</li> <li>• Make sure the sensor is in a normally dry condition</li> </ul>
5. "No TSnr"	<ul style="list-style-type: none"> <li>• Temperature sensor which is embedded in PMC2800-TMP is not wired to main controller OR not working properly. Verify wiring OR replace with new PMC2800-TMP pulse card.</li> </ul>


**ARJAY ENGINEERING TECHNICAL SUPPORT**

**(800) 387-9487 or +1 (905) 829-2418**

[www.arjayeng.com](http://www.arjayeng.com)

## 7.0 FLOW CHARTS

### NORMAL OPERATING DISPLAY




**Note 1: Data Entry**

Press <▲> / <▼> key to increase / decrease the digital value.

Press <SELECT> key to move the cursor.


VIEW MENU



Note 1: Data Entry  
 Press <▲> / <▼> key to increase / decrease the digital value.  
 Press <SELECT> key to move the cursor.

**\* SHOWN ONLY IF ENABLED BY FACTORY**

**CHANGE MENU**



Note 1: Data Entry  
Press <▲> / <▼> key to increase / decrease the digital value.  
Press <SELECT> key to move the cursor.

Note 2: High & Low Selection  
Press <▲> / <▼> key to toggle between v (low) & v (high) action.

Note 3: Yes & No Selection  
Press <▲> / <▼> key to toggle between Yes & No action.

**\* SHOWN ONLY IF ENABLED BY FACTORY**